

# Active Directory Domain Environment Deployment and Permission Management Report

---

## Basic Information


Name	Gaoyuan Zhang
Student ID	B00961366
Date	October 26, 2025
Environment	Oracle VirtualBox + Windows Server 2022 + Windows 11
Objective	Build a complete Active Directory (AD) domain environment in a virtualized lab, enabling user management, group policy deployment, and file-sharing permission control.
File Name	AD_Lab_Deployment_Report_EN_Full_GaoyuanZhang_B00961366.docx

## Experiment Steps and Results

### Step 0: Prepare Virtual Machines and ISO Images


Description: Two virtual machines were created in Oracle VirtualBox — one for Windows Server 2022 and another for Windows 11. Server01 was configured with 4–8GB RAM, 60GB+ disk, and two CPUs. The Windows 11 client had 4GB RAM and 40GB+ disk. Installation ISO files for both systems were attached for setup.

### Step 1: Configure VirtualBox Network Settings



Description: Both virtual machines were configured with two network adapters: Adapter 1 (Host-Only) for internal domain communication.

### Step 2: Install Windows Server (Domain Controller)



Description: Installed Windows Server 2022 Standard (Desktop Experience). After installation, the hostname was changed to SERVER01 and the system was rebooted. This server will act as the domain controller for the lab environment.

### Step 3: Configure Static IP for Domain Controller

```
Administrator: Command Prompt
C:\Users\Administrator>ipconfig /all
Windows IP Configuration

Host Name . . . . . : WIN-LH55MGL3A3H
Primary Dns Suffix . . . . . : lab.local
Node Type . . . . . : Hybrid
IP Routing Enabled. . . . . : No
WINS Proxy Enabled. . . . . : No
DNS Suffix Search List. . . . . : lab.local

Ethernet adapter Ethernet:

Connection-specific DNS Suffix . . . . . : Intel(R) PRO/1000 MT Desktop Adapter
Description . . . . . : Intel(R) PRO/1000 MT Desktop Adapter
Physical Address . . . . . : 08-00-27-6C-02-5A
DHCP Enabled. . . . . : No
Autoconfiguration Enabled . . . . . : Yes
Link-local IPv6 Address . . . . . : fe80::2121:a20d:beaa:1470%2(PREFERRED)
IPv4 Address. . . . . : 192.168.56.10(PREFERRED)
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :
DHCPv6 IAID . . . . . : 101187623
DHCPv6 Client DUID. . . . . : 08-01-00-01-30-8E-12-93-08-00-27-6C-02-5A
DNS Servers . . . . . : ::1
                                127.0.0.1
NetBIOS over Tcpip. . . . . : Enabled

C:\Users\Administrator>EVENTS
```

Description: In Network Connections (ncpa.cpl), the Host-Only adapter was assigned a static IP of 192.168.56.10 with subnet mask 255.255.255.0. DNS was set to 192.168.56.10 (self-reference). The NAT adapter remained on DHCP for internet connectivity. Verified connectivity using ping and ipconfig.

## Step 4: Install AD DS + DNS and Promote to Domain Controller

The screenshot shows the Windows Server Manager interface. The left navigation pane is visible with options like Dashboard, Local Server, All Servers, AD DS (which is selected and highlighted in blue), DNS, and File and Storage Services. The main content area has two sections: 'SERVERS' and 'EVENTS'.  
**Servers:** A table titled 'All servers | 1 total' showing one server: WIN-LH5SMGL3A3H (IP 192.168.56.10) which is online and has performance counters not started. The last update was 10/26/2025 at 5:23:06 PM.  
**Events:** A table titled 'All events | 18 total' showing three warning events from Microsoft-Windows-ActiveDirectory\_DomainService. The first event (ID 3054) is for Directory. The second (ID 3051) and third (ID 1539) are also for Directory.

Description: Through Server Manager → Add Roles and Features, installed Active Directory Domain Services (AD DS) and DNS Server roles. Promoted SERVER01 to a new forest with the root domain name lab.local. Set DSRM password, completed the wizard, and rebooted. Login now appears as LAB\Administrator.

## Step 5: Verify Domain Controller Health

```
C:\Users\Administrator>nslookup _ldap._tcp.dc._msdcs.lab.local
DNS request timed out.
    timeout was 2 seconds.
Server:  UnKnown
Address:  ::1

Name:      _ldap._tcp.dc._msdcs.lab.local

C:\Users\Administrator>nltest /dsgetdc:lab.local
DC: \WIN-LHSSMGL3A3H.lab.local
Address: \192.168.56.10
Dom Guid: e4f6c514-c042-42e4-be59-485f7d067122
Dom Name: lab.local
Forest Name: lab.local
Dc Site Name: Default-First-Site-Name
Our Site Name: Default-First-Site-Name
Flags: PDC GC DS LDAP KDC TIMESERV GTIMESERV WRITABLE DNS_DC DNS_DOMAIN DNS_FOREST CLOSE_SITE FULL_SECRET MS_DS_8_0_5_9 DS_10 KEYLIST
The command completed successfully


C:\Users\Administrator>
```


Description: Verified the AD installation using diagnostic commands: nslookup \_ldap.\_tcp.dc.\_msdcs.lab.local and nltest /dsgetdc:lab.local confirmed proper domain resolution. Opened AD tools (gpmc.msc, dsa.msc) to ensure AD DS and DNS services were running correctly.

## Step 6: Create Organizational Units (OU) and Users

⌚ Screenshot Placeholder (Insert screenshot for this step).

Name	Type	Description
computers	Organizational	
Departments	Organizational	
Users	Organizational	






Description: In Active Directory Users and Computers (dsa.msc), created OUs for Departments, Users, and Computers. Under Departments, created IT, Employee, and Admin OUs. Created users alice (Admin) and bob (Employee), and added them to corresponding security groups.

## Step 7: Configure Client Static IP

📸 Screenshot Placeholder (Insert screenshot for this step).


Description: Configured the Windows 11 client (WIN11) with Host-Only IP 192.168.56.20, subnet mask 255.255.255.0, and DNS 192.168.56.10. This allows the client to communicate with SERVER01 and resolve lab.local through the domain controller.

## Step 8: Join Client to Domain



Description: On the Windows 11 client, changed the system domain to lab.local under System → About → Rename this PC (Advanced). Entered domain credentials LAB\Administrator. After rebooting, verified domain login with LAB\alice credentials.

## Step 9: Deploy a Unified Wallpaper Policy via GPO



### Description:

A new Group Policy Object (GPO) named **WallpaperPolicy** was created under the domain *lab.local*.

This policy enforces a unified desktop wallpaper for all domain users to maintain a consistent corporate appearance.

In **Group Policy Management Editor**, the following configuration was applied:

User Configuration → Administrative Templates → Desktop → Desktop → Desktop Wallpaper



The wallpaper path was set to:



\\SERVER01\Wallpaper\background.jpg

and the wallpaper style was set to **Fill**.

After running gpupdate /force on the client and re-logging in,  
all domain users' desktops displayed the same background, confirming successful policy  
deployment.

## **Step 10: Set Up Shared Folders and Verify Permissions**





**Step Department Shares**

**Basic Details - Server: DC01**

**Shares**

Name	Description	Access
IT	Contains IT department shares	Everyone
HR	Contains HR department shares	Everyone
Employee	Contains Employee department shares	Everyone
Admin	Contains Admin department shares	Everyone

**Comments**

**Updates:**

- Re-enforcing security information for new users and changes that it's important to only change from this screen.
- Remove the share name if no longer needed.
- Apply security to the share if no longer needed.

**Advanced Security: Deny by Group:**

Group	Access
IT	Deny
HR	Deny
Employee	Deny
Admin	Deny
Guest	Deny
PowerUser	Deny
Administrator	Deny

**Share Map: Share 11**

**IT Share 11**

**General**

**Shares**

Name	Description	Access
IT	Contains IT department shares	Everyone
HR	Contains HR department shares	Everyone
Employee	Contains Employee department shares	Everyone
Admin	Contains Admin department shares	Everyone

**Comments**

**Updates:**

- Re-enforcing security information for new users and changes that it's important to only change from this screen.
- Remove the share name if no longer needed.
- Apply security to the share if no longer needed.

**Advanced Security: Deny by Group:**

Group	Access
IT	Deny
HR	Deny
Employee	Deny
Admin	Deny
Guest	Deny
PowerUser	Deny
Administrator	Deny

**Share Map: Share 12**

**HR Share 12**

**General**

**Shares**

Name	Description	Access
IT	Contains IT department shares	Everyone
HR	Contains HR department shares	Everyone
Employee	Contains Employee department shares	Everyone
Admin	Contains Admin department shares	Everyone

**Comments**

**Updates:**

- Re-enforcing security information for new users and changes that it's important to only change from this screen.
- Remove the share name if no longer needed.
- Apply security to the share if no longer needed.

**Advanced Security: Deny by Group:**

Group	Access
IT	Deny
HR	Deny
Employee	Deny
Admin	Deny
Guest	Deny
PowerUser	Deny
Administrator	Deny

**Share Map: Share 13**

**Employee Share 13**

**General**

**Shares**

Name	Description	Access
IT	Contains IT department shares	Everyone
HR	Contains HR department shares	Everyone
Employee	Contains Employee department shares	Everyone
Admin	Contains Admin department shares	Everyone

**Comments**

**Updates:**


- Re-enforcing security information for new users and changes that it's important to only change from this screen.
- Remove the share name if no longer needed.
- Apply security to the share if no longer needed.


**Advanced Security: Deny by Group:**

Group	Access
IT	Deny
HR	Deny
Employee	Deny
Admin	Deny
Guest	Deny
PowerUser	Deny
Administrator	Deny

Description: Created shared folders D:\Share\IT and D:\Share\HR on DC. Configured Share and NTFS permissions — IT folder accessible only to IT group and Admin group, Employee folder accessible only to Employee group and Admin group, Admin folder only to Admin group. On the client, \ WIN-LH5SMGL3A3H \IT, \ WIN-LH5SMGL3A3H \Admin, and \ WIN-LH5SMGL3A3H \Employee verified correct access isolation between groups.

## Step 11: Enable Remote Desktop Access





Description: Enabled Remote Desktop under System → Remote Desktop → Allow remote connections to this computer. Firewall automatically opened TCP port 3389. Verified service status using netstat -an | find "3389". From the host or client machine, connected to SERVER01 via mstsc using LAB\Administrator credentials.

## **Appendix A: Command Summary**

Command	Description
ipconfig /all	Display all network configuration details.
ping 192.168.56.10	Test connectivity with the domain controller.
nslookup lab.local	Verify DNS resolution for the domain.
nltest /dsgetdc:lab.local	Retrieve information about the domain controller.
gpupdate /force	Force immediate Group Policy update.
net use	List all mapped network drives.
netstat -an   find "3389"	Check if Remote Desktop (RDP) service is listening.

## **Appendix B: Summary and Reflection**

- Successfully deployed a Windows Server 2022 Active Directory domain environment.
- Client successfully joined the domain and authenticated with domain credentials.
- Group Policy Objects (GPOs) were successfully applied and verified.
- File sharing permissions were properly configured and enforced per department.
- Remote Desktop access to the domain controller was successfully enabled.

Through this lab, I gained hands-on experience in setting up and managing a Windows domain environment. I learned how to integrate DNS, AD DS, Group Policy, and file-sharing permissions within an enterprise network. This exercise demonstrated how to securely manage users and systems within an organizational infrastructure.